Teacher's quide:

BenQ Board Pro RP04 Basics





Logging in

The BenQ Board offers multiple secure ways for you to log in and begin teaching.



NFC login


Use NFC to quickly log into the board, all your apps, and connected cloud drives by holding your NFC card up to the board's NFC reader.

Your NFC card must be bound to your BenQ account before you can use it to log in. For more information, see Setting up your AMS account.

QR code login

Tap **Login**, then tap the **QR Code** button. Scan the QR code with your mobile device to log into the board.

Note: You only need to enter your credentials the first time you log in on your mobile device using the QR code method.



SSO login

Tap **Sign in with SSO** to log into the board with your Google, ClassLink, Clever, Entra ID, or other SAML-based credentials.









Google

gle ClassLink

Clever

SAML

Credentials login

Manually enter your BenQ account username and password to log into the board.

Guest login

Tap Guest on the login screen to use the board as a guest user. In this mode, your access to the board's functions will be limited and you will not be able to access your connected cloud drives.



Setting up your BenQ account

Personalize your BenQ Board and easily access your cloud storage on the board by setting up your account on BenQ Account Management System (AMS).

Getting to AMS

Go to ams.beng.com on a web browser and log in with your BenQ account. Once logged in you can customize the following:

General settings

Set an optional idle

Change your profile photo.

Avatar

session logout time so the board logs out of your account when not in use.

Wallpaper

Change the wallpaper on your BenQ Board.

Apps

Choose apps to pin to your board's Home screen.

Bookmarks


Add website shortcuts that you can access on the board under Bookmarks.

Linked drives

Link your cloud storage drives or network drives to access your files on the board.

NFC cards

IT admins can allow you to bind up to three NFC cards for easy logging into your board. Your IT admin can also bind NFC cards to your account for you.





Home screen

The Home screen is your starting point to accessing the apps, tools, and widgets on the BenQ Board.





BenQ Board Settings

The BenQ Board has various settings that you can adjust to suit your needs, depending on your user privileges.

To access the BenQ Board Settings, tap ♠ on the sidebar or taskbar, press ۞ on the control panel, or swipe up at the bottom of the screen.

Connection

Switch between input sources, including the Android OS, and adjust the board's brightness and volume.


Display

Change the picture mode, aspect ratio, input source names, and other display settings.

Picture modes

- 1. Eco
- 2. Standard
- 3. Bright
- 4. Soft
- 5. Custom, which allows you to adjust the sliders for brightness, contrast, and saturation.





Audio

Mute the board, adjust the sound balance, and change the preset sound modes.

Sound modes

- 1. Standard
- 2. Cinema
- 3. News
- 4. Sports

Advanced

Depending on your permissions, you can gain access to a number of advanced settings, including toggling the sidebar, front USB-C charging, air ionizer, and more.

Blank screen

Tap to make the screen go blank. Tap the screen again to exit blank screen mode.

Android settings

Tap ﴿ to access the board's Android settings menu.



Switching Sources

The BenQ Board allows you to switch input sources for you to display multimedia content in various ways.

Switching input sources

To switch input sources, go to the **Connection tab in the** board's **Settings** menu. There are several ways to do this:

- 1. Press 🐯 on the board's control panel.
- 2. Press 🕾 on the BenQ Board remote control.
- 3. Press → on the sidebar menu.
- 4. Press 🝙 on the taskbar.
- 5. Swipe up from the bottom of the screen.

Input

Display your device screen and play audio and video content on the BenQ Board. Supported ports:


- HDMI
- DisplayPort
- · VGA with 3.5 mm audio-in jack
- · 3.5 mm mic-in jack

Touch

Control your laptop from the BenQ Board touchscreen with touchback. Supported ports:

- · USB-C
- · Touch USB with HDMI

★ Tip: The board's USB-C ports support power charging for your connected devices.






Note | For wireless sharing, see the **InstaShare 2 Guide**.




The control panel includes physical buttons and the NFC sensor to help you control the display and its settings as well as quickly log in.




Sidebar

The BenQ Board features a sidebar for easy access to board interface controls and tools. To access it, tap the bars on the left or right of the board's screen.



Floating Tool

The Floating Tool gives you easy access to tools while using apps, browsing sites, or interacting with connected devices.



Touchscreen Gestures

The BenQ Board lets you use hand gestures to navigate and modify the Home screen, access the Settings menu, and more.




Tap an app or widget

Open apps or interact with widgets.




Hold and drag an app, widget, or window

Move apps, widgets, or windows.



Swipe left or right with one finger Change pages on the Home screen.



Swipe up from the bottom edge of the screen

Open the Settings menu.




Tap and hold two fingers Hold for 3 seconds anywhere on the board to launch the Floating Tool.

Apps and Bookmarks

The BenQ Board offers a variety of ways to access your apps and bookmarks.


Apps

The BenQ Board boasts a range of built-in apps designed for interactive displays, plus the option to expand your toolkit with additional apps.






- Tap and hold apps to move or remove them.
- Hold and drag apps to the right hand side of the screen to add a new Home screen page.



Bookmarks


Create bookmarks to your favorite websites by logging into your BenQ account on a web browser.

Once you've saved your bookmarks, tap on the board, then tap the **Bookmarks** tab to access them.



Widgets

Display important information on your Home screen by adding widgets. Show air quality, add a calendar, paste sticky notes, and more.




Remote Control

Control your BenQ Board from anywhere in the classroom with the remote control to enhance your teaching experience.



File Access

You can access all your files, including cloud storage, local files, networks drives, and even files on your USB drive, with AMS Files.



Multi-window mode

Open up to six different apps or an input source in separate windows and interact with them on the board simultaneously for enhanced sharing and collaboration.

Enabling multi-window mode

- 1. Tap 🚹 .
- 2. Tap Advanced.
- 3. Enable Multi-window mode.


Once enabled, open an app or input source then tap **Multi-win-dow mode** on the sidebar to turn it into a movable window.

Multi-window mode options bar

- Take up left side of screen
- Take up right side of screen
- **■** Pin window
- Resize window
- Full screen
- X Close window

Input source exclusive tools

- ☑ Take a screenshot
- Switch input source





If you set a window to take up the left or right side of the screen, you can tap or to make the window switch sides.



Using a camera


Connect a camera to the BenQ Board for immersive remote learning and video conferencing on a large touch display.

Connecting a camera

The board has ports on the front and side for you to plug a webcam in, as well as the USB-C port on top of the board designed for the Zoom™ Certified BenQ DV01K AI Camera.

To use this camera:

- 1. Download the DV01K Camera app from the BenQ Store.
- 2. Open the app on the board.
- 3. Download your preferred video conferencing app from Google Play or use the web browser version of your preferred video conferencing platform on the board or by connecting your laptop or mobile device to the board.



Choosing a camera source

You can select your camera and mic input sources in your video conferencing app to ensure you're seen and heard.

To set your camera as the default:

- 1. Open the **Settings** menu.
- 2. Tap Advanced → Accessories.
- 3. Under **Webcam**, tap **Other** and select your camera from the drop-down list.




You can also use a camera in EZWrite. Simply tap \Box , then tap \bigcirc .

→ DV01K AI features:

Al auto framing & voice tracking
Keeps speakers in frame.

Reduces background noises for crystal-clear audio.



InstaShare Button

The BenQ InstaShare Button lets you share your laptop screen to your BenQ Board, and enables touchback, with just a tap.

Using the InstaShare Button

To start, plug the InstaShare Button into a USB-C port on your laptop and wait for the light to turn solid green, then press the button to start screen sharing.

The InstaShare Button is in split-screen mode by default, letting multiple users share screens at once. Press the **full-screen button** to switch to full-screen mode, showing only your screen. Press it again to return to split-screen mode.


Touchback

Use the board to control your Windows laptop, including scrolling and clicking, with touchback.

Video calls

Start a video call on your laptop and use the board's microphone and camera for enhanced audiovisual quality.

Note | A steady blue indicator light color means the InstaShare Button is sharing to the board. A red indicator light means the device failed to pair to the board.



The InstaShare Button is compatible with these operating systems:







Windows macOS ChromeOS

InstaShare 2



The InstaShare Button works with InstaShare 2, allowing up to 9 devices to cast content wirelessly.




Connecting Bluetooth® devices

You can easily connect and use Bluetooth devices, such as a keyboard or mouse, with the BenQ Board for enhanced teaching.

Connection methods:

1. USB adapter

If your Bluetooth device is equipped with a USB adapter, simply plug the adapter into one of the board's USB ports and you can begin using your Bluetooth device.




- Ensure that Bluetooth is enabled on the board. To do this, either you or your IT admin can tap > Settings > Connected devices > Connection preferences > Bluetooth and enable Use Bluetooth.
- Bluetooth on the BenQ Board does not support Bluetooth microphones.

2. Pairing to the board

If your Bluetooth device doesn't have a USB adapter, you'll need to pair it to the BenQ Board. To do this:

- 1. Tap -> Settings > Connected devices
- 2. Make sure your Bluetooth device is ready to pair by referring to its manual.
- 3. Tap **Pair a new device** and select your device from the list.



Notes

Playing external media

Connect a media device, such as a Blu-ray player or set top box, to the board to further expand your lesson's multimedia options.

Plug and play

Easily connect a media player to the board with your device's input cable. There are 3 connection methods:

Video and audio in one cable:

- HDMI
- DisplayPort

Video cable and audio cable:

- VGA (video)
- 3.5 mm audio-in jack (audio)


Audio only

• 3.5 mm mic-in jack

Choose your player

To switch to an external media source, tap [↑] on the home screen taskbar. For more information, see Switching sources.







Press Input on the board's remote control to quickly switch sources.



Power off, sleep, and blank screen

The BenQ Board offers various options for turning it off, putting it to sleep, or simply blanking the screen.

Power on and off

Tap \bigcirc when the board is off to turn it on. Hold \bigcirc for 3 seconds to begin turning the board off.

To force power off the board, hold \bigcirc for 10 seconds. Only do this when the board is unresponsive.

Sleep

Tap \circlearrowleft when the board is on to put it to sleep. Tap \circlearrowleft again to wake the board from sleep mode.

Use sleep mode to easily cut down on energy consumption while ensuring the board is ready to use right away.

Blank screen

Turns the screen blank so you can play audio with no video, or turn the screen blank and mute the audio. Turn the screen blank from the remote control or from the board's settings menu.

To adjust the settings for this feature:

- 1. Open the **Settings** menu.
- 2. Tap Display > Advanced > Blank button.
- 3. Select either Blank screen & mute or Blank screen only.

Use blank screen to play music on the board for students to study to, or to play lullables for preschool students, for example.





Your school's IT admin can remotely set sleep mode and power schedules for your board to further help with energy consumption efforts.

Blank screen button