

Read me before downloading the firmware

Apply BenQ Model: RE6501, RE7501, RE8601, RE9801

Please read carefully for the below instruction:

There are two ways to identify which firmware should be downloaded for your display:

Method 1 – from the Part Number

- BenQ Part Number can be found on the spec label at rear side of the unit.
 If you are having trouble finding the Part Number, please provide the Serial Number to local BenQ Support and we can check it for you.
- 2. Check the last 3 digits of the Part Number:

BenQ part number

Model	Part Number
RE6501	9H.F6YTK.xxx
RE7501	9H.F71TK.xxx
RP8601	9H.F72TK.xxx
RE9801	9H.F79TK.xxx

3. Kindly refer to the last 3 digits of the part number and download the corresponding firmware.

Model	SKU	FW version
RE6501	DE1, DN1, DT2, DA2, DT3	v1. <mark>0</mark> .0.xx
	DE3, DP3, DA4, DN4, DC4,	v1.2.0.xx
	DE6, DP6, DA6, DE7, DP7	v1.3.0.xx
RE7501	DE1, DA1, DN1, DC1, DT1, DP2, DA2, DN2, DT2	v1.0.0.xx
	DE4, DP4, DN4, DT4, DA5, DA8, DE9, DP9	v1.1.0.xx
RE8601	DEI, DPI, DAI, DNI, DCI, DTI, DE2, DP2, DA2, DN2, DT2, DT3, DAA, DEB, DPB	v1. <mark>0</mark> .0.xx
RE9801	DP1	v1.0.0.xx

Note: Last 2 digits of firmware version will depend on the current latest firmware.

4. There are 2 types of firmware available for download. Kindly select the one that is suitable for you.

I OTA FW	Upgrade the system firmware and keep all the user setting
Image_FW	Upgrade the system firmware and reset everything




You can find the firmware upgrade SOP from the zip file that you downloaded.

Method 2 - from the software/firmware version on the display

Check the software version currently on your display.
 It can be checked under the OSD menu > About



Or through the DMS cloud



2. Refer to the 2nd digit of the software/firmware version and download the corresponding firmware.

Model	Software version 1	Software version 2	Software version 3
RE6501	v1. <mark>0</mark> .0.xx	v1. <mark>1</mark> .0.xx	v1. <mark>2</mark> .0.xx
RE7501	v1. <mark>0</mark> .0.xx	v1. <mark>1</mark> .0.xx	-
RE8601	v1. <mark>0</mark> .0.xx	-	-
RE9801	v1. <mark>0</mark> .0.xx	-	-

3. Kindly refer to the 2nd digit of the firmware version and download the corresponding firmware.



Model	Software version	Firmware version to be downloaded
	v1. <mark>0</mark> .0.xx	v1. <mark>0.</mark> 0.xx
RE6501	v1.1.0.xx	v1.1.0.xx
	v1. <mark>2</mark> .0.xx	v1. <mark>2</mark> .0.xx
RE7501	v1. <mark>0.</mark> 0.xx	v1. <mark>0</mark> .0.xx
	v1.1.0.xx	v1.1.0.xx
RE8601	v1. <mark>0.</mark> 0.xx	v1. <mark>0</mark> .0.xx
RE9801	v1. <mark>0.</mark> 0.xx	v1. <mark>0</mark> .0.xx

Note: Last 2 digits of firmware version will depend on the current latest firmware.

4. There are 2 types of firmware available for download. Kindly select the one that is suitable for you.

I OTA FW I	Upgrade the system firmware and keep all the user setting
lmage_FW	Upgrade the system firmware and reset everything

You can find the firmware upgrade SOP from the zip file that you downloaded.